### **KÄRCHER**

# FloorPro High Gloss Crystallising Agent, powder RM 775

Powder for wet crystallisation of calcareous floors made of marble, terrazzo and artificial stone. Crystallisation hardens the floor, increases its sturdiness and ensures a high gloss.

**pH 1.4** in concentrate











#### Properties

- Effective high-gloss crystallising agent for all calcareous stone floors such as marble, terrazzo, artificial stone
- Powder
- Creates a hard-wearing surface by compacting the stone
- Creates a mirror-like high gloss
- The character of the stone is preserved
- Makes future cleaning of the surface easier (less resoiling)
- Extremely economical
- Can be walked on immediately after application
- NTA-free

Usa	ge	ao	tio	ns

Single disc machines

Application areas	
Car dealership and garage	Calcic stone floors
Building cleaning	Calcic stone floors
Hotels, gastronomy, catering	Calcic stone floors
Municipal	Calcic stone floors
Retail	Calcic stone floors

nnı	cal	

Container sizes	Packaging unit	Part number
5 kg	1 Piece(s)	6.295-117.0



#### Application

#### Single-disc machines - crystallising

- Clean surface thoroughly.
- Rinse with plenty of clear water and soak in water until all dirt and cleaning agent residues have been removed.
- Leave to dry.
- Set up the device with the appropriate pad.
- Mix approx. 30 g of powder/m² with 90 ml of water into a paste.
- Per m², distribute paste evenly over the surface with a pad.
- Polish surface immediately with device until a high-gloss is achieved.
- Brush off the crystallising agent from the surface with plenty of water and standard brushes.
- Vacuum surface with wet and dry vacuum cleaner.

#### Instructions for use

- Test on an inconspicuous part for material compatibility.
- Fine grind any heavy wear and scratches on the floor before treatment.
- Store in a dry place.

#### Warnings and safety recommendations according to EC Directives

- Danger
- H302 + H312 Harmful if swallowed or in contact with skin
- H318 Causes serious eye damage
- P280a Wear protective gloves / eye protection / face protection.
- P301+P312a IF SWALLOWED: Call a POISON CENTER/doctor if you feel unwell.
- P330 Rinse mouth.
- P302 + P352a IF ON SKIN: Wash with plenty of water.
- P305 + P351 + P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- P310 Immediately call a POISON CENTER/doctor.

#### Further information

Material Safety Data Sheet (MSDS)

## Contents Cleaning method Dosage Yield 1 kg Crystallising 30 g/m²undiluted 30 m²